

OPERATION MANUAL


R/C Stunt Car Series --- Happy Rollover Car

Model No.: 9002 Series


- Not suitable for children under 3
- Read through this manual before use
- Use under adult's guidance

FEATURES

- Transmitter**
- Channel: 4
 - Battery: 1 9V battery



- Transmitter**
1. Aerial
 2. Indicator
 3. L/R Turn Lever
 4. F/B Run Lever




Transmitter

5. Power Switch
6. 9V Battery
7. Battery Cover
8. Power Switch

Car

- Multi-channel and multi-functional, can perform rollover and other stunts.
- Use 4 AA rechargeable batteries or alkaline batteries.
- Direct charging possible using charging jack under the chassis.



Car


9. Battery Box
10. 4 Batteries
11. Rear Wheel
12. Front Wheel
13. Battery Box Fastener
14. Charging Jack
15. Tail Wheel

CHARGING

1. Plug the charger to an indoor 220V AC power socket.
2. Plug the outlet line of the charger to the charging jack underneath the car.
3. Set the power switch underneath the car to ON. (Note: This step is necessary. Otherwise, charging won't be possible.)
4. Optimum charging time is 6 hours.


CAUTIONS:

1. Charge only with our special 4.8V charger. Charging with other unspecified chargers may cause damages to the circuits in the car.
2. Make sure the power switch underneath the car is set to ON when charging.
3. Do not charge for too long. (6 hours is sufficient for charging. Overcharging may shorten battery's useful life or may even totally destroy the battery.)
4. Never try to charge batteries that are not rechargeable ones.








SAFETY CAUTIONS

- Never give this toy to children under 3.
- After the power of this car is turned on, keep your fingers, hair, and clothes away from the wheels to avoid accidental damages.
- Do not try to catch the car by hand while it is in action.
- Keep the transmitter and the car away from any heat sources, such as electric stove, gas stove, or strong sunlight.
- Do not play with it in a dangerous place, such as on a road, or on a slope.
- Do not wet the car. Do not play with it outdoors in a rainy day.
- Do not play with it on the sands.
- Avoid bumping into any other articles, such as other people or glass, when playing.
- Do not allow children to disassemble the transmitter or the car by themselves.
- If the car is broken during use, it should be checked by adult or repaired, when necessary, by professional technician before it can be reused.



OPERATIONS

1. Fully extend the aerial on the transmitter.
2. Set the power switches underneath the transmitter and the chassis to ON.
3. Use the control levers on the transmitter to control the car to run or perform various stunts.

<p>① Forward Run</p> 	<p>② Backward Run</p> 
<p>③ Rollover Stunts</p> 	
<p>④ Wheelie Stunt with Front Wheels Rotating Clockwise</p> 	
<p>⑤ Wheelie Stunt with Front Wheels Rotating Counterclockwise</p> 	

Notes: 1. If the car slows down during actions or becomes unable to roll over smoothly, it may be caused by insufficient power. Charge the batteries when necessary.

2. Make sure the power switch underneath the car is turned off after use. Otherwise, power of the batteries in the car may be soon consumed.